	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00 Page : 1 of 18

ELAUSYS

INV-KNX-GO

KNX Gateway for GoodWe inverters

User Manual





	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 2 of 18

TABLE OF CONTENT

1. INTRODUCTION	3
2. OVERVIEW	4
2.1USAGE & LIMITATION	4
2.2CONNECTION DIAGRAM	4
2.3FRONT PANEL	5
2.4SOFTWARE	5
3. PARAMETERS	6
3.1INVERTER SETTINGS	6
4. LOGIC FUNCTIONS	7
5. COMMUNICATION OBJECTS	8
5.1GENERAL	8
5.2INVERTERS OBJECTS	8
5.3GROUP OBJECT LIST.....	11
6. CONFIGURATION	14
6.1NETWORK CONFIGURATION.....	14
6.2KNX PHYSICAL DEVICE	15
6.3ETS PARAMETERS.....	15
6.4ETS GROUP OBJECTS.....	16
6.5INVERTER CONFIGURATION.....	17
7. FIRMWARE VERSION	18
8. DATASHEET	18

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 3 of 18


1. INTRODUCTION

The KNX gateway for GoodWe inverters provides a simple solution to transfer all relevant data from GoodWe inverters to KNX.

It allows integrators to take advantage of a fully integrated solar panel inverter, the data can be used to optimize energy consumption, monitoring, trending or to trigger specific action in the KNX installation.

Main features:

- KNX Interface for GoodWe inverters serie
- Monitoring of Energy, Power, current, voltage, frequency, temperature, ...
- Connected to the inverter over Ethernet
- Galvanic insulation from the KNX bus
- Configurable refresh rate of inverter data
- DIN rail mounted
- Auxiliary power supply 12-30VDC
- KNX logic module including logic gates, sequences, triggers, math operation and weekly calendar events.

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00 Page : 4 of 18

2. OVERVIEW


2.1 USAGE & LIMITATION

This gateway is intended to be used with a GOODWE inverter compatible with the modbus interface definition. Please refer to the inverter provider to check if your model is compatible with modbus TCP or contact us.


2.2 CONNECTION DIAGRAM

The KNX bus is connected on the top side of the gateway.
An external power supply 12-30VDC is required and connected on the bottom side of the module, beside the RJ45 connector for the ethernet cable.



	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 5 of 18

2.3 FRONT PANEL




The front panel is equipped with two green status LED:

Network: Physical connection to the ethernet network is established.
 Connected: Communication with the inverter is established.

Button "P" : KNX Programming mode button
 Red LED : KNX Programming status LED

2.4 SOFTWARE

The KNX Interface is configured using the ETS tool, the free ETS Demo version can be [downloaded](#) from the website of KNX Association. The free version allows to configure up to 5 KNX modules in a project, the KNX gateway is only one module, all devices can be configured using this version.

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 6 of 18


3. PARAMETERS

The KNX interface parameters are defined in the “parameters” tab of the device, in the ETS project.

3.1 INVERTER SETTINGS

The following parameters are defined in the inverter settings section of the parameters:

PARAMETER	VALUES	DESCRIPTION
AC Network	<ul style="list-style-type: none"> ▪ Single phase (default) ▪ Tri-Phase 	Type of AC network
Number of PV Circuits	<ul style="list-style-type: none"> ▪ 1 ... 4 	Number of solar panel circuits to monitor
Inverter model	<ul style="list-style-type: none"> ▪ 0...255 	8 = GOODWE
Refresh rate (min)	<ul style="list-style-type: none"> ▪ 0...255 	Cyclic rate of data polling from the inverter.
Battery 1	<ul style="list-style-type: none"> ▪ Not Used / Used 	Display group objects to monitor the status of battery 1
Battery 2	<ul style="list-style-type: none"> ▪ Not Used / Used 	Display group objects to monitor the status of battery 2

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 7 of 18


Powermeter	▪ Not Used / Used	Display group objects to monitor the powermeter value
Timezone	▪ UTC-11... UTC+14	Timezone where the device is installed. It is used for logic functions based on the weekly calendar.
Daylight saving time	▪ Not Used / Used	Set if daylight saving is used where the device is installed. It is used for logic functions based on the weekly calendar.
Device Options	Text string	Device options are not available on this device.

4. LOGIC FUNCTIONS

The KNX logic module is a virtual extension module that is part of the ETS application on the inverters gateways. Each logic module includes 8 logic functions including logic gates, sequences, triggers, math operation and weekly calendar events.

- Up to **64 logic functions** using extension modules
- **Logic Gate** with 8 inputs, configurable output delay and inversion
- **Sequence** with 4 steps, configurable outputs delays and datatypes
- **Trigger** with inputs logic, delays and weekly calendar events
- **Math** operations with configurable objects type and delays

Refer to the KNX Logic Module manual for more details on each function.

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 8 of 18

5. COMMUNICATION OBJECTS

5.1 GENERAL


General communication objects of the device.

GO	NAME	DESCRIPTION
1	Module status	Sends 0 when the module is operating normally, sends an error code when applicable.
2	Firmware version	Returns the firmware version of the device when the object is read.


5.2 INVERTERS OBJECTS

GO	NAME	DESCRIPTION
3	AC Current	AC Total Current value (NOT USED)
4	AC Current A	AC Current phase A
5	AC Current B	AC Current phase B
6	AC Current C	AC Current phase C
7	AC Voltage	AC Total Voltage (NOT USED)
8	AC Voltage AB	AC Voltage phase AB (NOT USED)
9	AC Voltage BC	AC Voltage phase BC (NOT USED)
10	AC Voltage CA	AC Voltage phase CA (NOT USED)
11	AC Voltage AN	AC Voltage phase AN
12	AC Voltage BN	AC Voltage phase BN
13	AC Voltage CN	AC Voltage phase CN
14	DC Current	DC Total Current value (NOT USED)
15	DC Voltage	DC Total Voltage (NOT USED)
16	PV1 Voltage	PV1 Voltage
17	PV1 Current	PV1 Current

18	PV2 Voltage	PV2 Voltage
19	PV2 Current	PV2 Current
20	PV3 Voltage	PV3 Voltage
21	PV3 Current	PV3 Current
22	PV4 Voltage	PV4 Voltage
23	PV4 Current	PV4 Current
24	AC Power	AC Power
25	DC Power	DC Power (NOT USED)
26	AC Frequency	AC Frequency
27	AC VA	AC Apparent power
28	AC VAR	AC Reactive power
29	AC PF	Power factor (NOT USED)
30	AC Energy	Total AC Energy
31	Efficiency	Inverter efficiency (NOT USED)
32	Insulation	Insulation resistance (NOT USED)
33	Temperature	Cabinet temperature
40	Daily Energy Yield	
41	Battery 1 Running Status	0: offline 2: standby 3: running 4: fault 5: sleep mode
42	Battery 1 power	> 0: charging < 0: discharging
43	Battery 1 SOC	Battery's state of capacity
44	Battery 1 current day charge	
45	Battery 1 current day discharge	
46	Battery 1 total charge	
47	Battery 1 total discharge	
48	Battery 2 Running Status	0: offline 2: standby 3: running 4: fault 5: sleep mode (NOT USED)


	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 10 of 18

49	Battery 2 power	> 0: charging < 0: discharging (NOT USED)
50	Battery 2 SOC	Battery's state of capacity (NOT USED)
51	Battery 2 current day charge	(NOT USED)
52	Battery 2 current day discharge	(NOT USED)
53	Battery 2 total charge	(NOT USED)
54	Battery 2 total discharge	(NOT USED)
55	Powermeter	> 0: charging < 0: discharging


	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 11 of 18

5.3 GROUP OBJECT LIST


GO	Name	Function	Size	Flags	Type ID	Type Name	Description
1	Module status	Status code	1 byte	C R - T -	20.011	DPT_ErrorClass_System	Device status
2	Firmware version	Text String	14 bytes	C R - T -	16.000	Character string	Firmware version of the device
3	AC Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Total Current value
4	AC Current A	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase A
5	AC Current B	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase B
6	AC Current C	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase C
7	AC Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Total Voltage
8	AC Voltage AB	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase AB value
9	AC Voltage BC	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase BC value
10	AC Voltage CA	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase CA value
11	AC Voltage AN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase AN value
12	AC Voltage BN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase BN value
13	AC Voltage CN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase CN value
14	DC Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	DC Total Current value
15	DC Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	DC Total Voltage
16	PV1 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV1 Voltage
17	PV1 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV1 Current
18	PV2 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV2 Voltage
19	PV2 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV2 Current

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 12 of 18

20	PV3 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV3 Voltage
21	PV3 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV3 Current
22	PV4 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV4 Voltage
23	PV4 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV4 Current
24	AC Power	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Power
25	DC Power	Actual value	4 bytes	C R - T -	14.056	Power (W)	DC Power
26	AC Frequency	Actual value	4 bytes	C R - T -	14.033	Frequency (Hz)	AC Frequency
27	AC VA	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Apparent power
28	AC VAR	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Reactive power
29	AC PF	Actual value	4 bytes	C R - T -	14.057	Power factor (cos phi)	Power factor
30	AC Energy	Actual value	4 bytes	C R - T -	13.013	Active energy (kWh)	Total AC Energy
31	Efficiency	Actual value	2 bytes	C R - T -	8.010	Percentage (%)	Inverter efficiency
32	Insulation	Actual value	4 bytes	C R - T -	14.056	Resistance (Ohm)	Insulation resistance
33	Temperature	Actual value	2 bytes	C R - T -	9.001	Temperature (°C)	Cabinet temperature
34	Status 1	Status code	2 bytes	C R - T -	-	-	Device specific satus code
35	Status 2	Status code	2 bytes	C R - T -	-	-	Device specific satus code
36	Status 3	Status code	2 bytes	C R - T -	-	-	Device specific satus code
37	Status 4	Status code	2 bytes	C R - T -	-	-	Device specific satus code
38	Status 5	Status code	2 bytes	C R - T -	-	-	Device specific satus code
39	Status 6	Status code	2 bytes	C R - T -	-	-	Device specific satus code
40	Daily Energy Yield	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
41	Battery 1 Running Status	Actual value	2 bytes	C R - T -	-	-	Status code
42	Battery 1 power	Actual value	4 bytes	C R - T -	14.056	Power (W)	

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 13 of 18

43	Battery 1 SOC	Actual value	1 byte	C R - T -	5.001	Percentage (%)	State of charge (%)
44	Battery 1 current day charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
45	Battery 1 current day discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
46	Battery 1 total charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
47	Battery 1 total discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
48	Battery 2 Running Status	Actual value	2 bytes	C R - T -	-	-	Status code
49	Battery 2 power	Actual value	4 bytes	C R - T -	14.056	Power (W)	
50	Battery 2 SOC	Actual value	1 byte	C R - T -	5.001	Percentage (%)	State of charge (%)
51	Battery 2 current day charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
52	Battery 2 current day discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
53	Battery 2 total charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
54	Battery 2 total discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
55	Powermeter	Actual value	4 bytes	C R - T -	14.056	Power (W)	


	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 14 of 18

6. CONFIGURATION

6.1 NETWORK CONFIGURATION

By default, the IP address of the KNX gateway is set to **192.168.1.51**


Using a laptop connected to the gateway, open a web browser and navigate to the IP address of the gateway.



The screenshot shows a web interface with a dark blue background. At the top, there are two tabs: 'Settings' (active) and 'FW Update'. The 'Settings' section is titled 'Settings' and contains two main panels: 'IP Parameters' and 'MB TCP Parameters'.
 In the 'IP Parameters' panel, there is a radio button for 'DHCP Client' which is unselected. Below it are input fields for 'Ip Address' (192.168.1.51), 'Device Mask' (255.255.255.0), 'Device Gateway' (192.168.1.1), and 'Mac Address' (0:ce:1f:d8:b5:4e).
 In the 'MB TCP Parameters' panel, there is a 'Mode' section with two radio buttons: 'Connect' (unselected) and 'Listen' (selected). Below it are input fields for 'Server Port' (502) and 'Uni Id' (0).
 At the bottom of the settings area, there is a 'Save' button with a downward arrow icon.

Set a fixed IP address of your choice for the KNX gateway and configure the modbus TCP settings as below:


- Mode : Connect
- Server IP : IP address of the inverter
- Server Port : modbus TCP port of the inverter
- Uni Id : modbus TCP UID of the inverter (default 247)

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 15 of 18

6.2 KNX PHYSICAL DEVICE

ELAUSYS devices are configured using the ETS tool. You should first download and install the free version of ETS tool before you continue.

The INV-KNX Interface must be assigned a physical address on the KNX network. Assign a free address to the module, in our example we choose 1.1.2.



6.3 ETS PARAMETERS

Once a KNX physical address is set, open the parameter tab to configure the interface.

1.1.30 ELAUSYS INV-KNX > General

<p>General</p>	<p>AC Network</p> <p>Number of PV circuits</p> <p>Inverter model</p> <p>Refresh rate (min)</p> <p>Battery 1</p> <p>Battery 2</p> <p>Powermeter</p> <p>Device options :</p>	<p><input type="radio"/> Single-phase <input checked="" type="radio"/> Tri-phase</p> <p>2</p> <p>0</p> <p>1</p> <p><input type="radio"/> Not used <input checked="" type="radio"/> Used</p> <p><input type="radio"/> Not used <input checked="" type="radio"/> Used</p> <p><input type="radio"/> Not used <input checked="" type="radio"/> Used</p> <p></p>
-----------------------	--	---

Select the type of AC network (single phase or tri-phase).


Select the number of solar panel circuits to monitor.

Set the **inverter model to 8 for GOODWE** inverters.

Choose the refresh rate (min) for the complete set of data.

Select if batteries or powermeter are available on the inverter.

Device options should remain empty.


	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 16 of 18

6.4 ETS GROUP OBJECTS

A group address (GA) must be assigned to each group object (GO) needed by the application. Open the Group Objects tab of the device and assign a GA to the objects as needed.


Number	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	Data Type	Priority
1	Module status	Status code	Status	0/0/1	1 byte	C	R	-	T	-	system err...	Low
2	Firmware version	Text string	FW	0/0/2	14 bytes	C	R	-	T	-	Character...	Low
3	AC Total Current	Actual value	Value	1/0/0	4 bytes	C	R	-	T	-	electric cur...	Low
7	AC Total voltage	Actual value	Value	1/0/1	4 bytes	C	R	-	T	-	electric po...	Low
14	DC Total Current	Actual value	Value	1/0/2	4 bytes	C	R	-	T	-	electric cur...	Low
15	DC Total voltage	Actual value	Value	1/0/3	4 bytes	C	R	-	T	-	electric po...	Low
16	PV1 Voltage	Actual value	Value	1/0/4	4 bytes	C	R	-	T	-	electric po...	Low
17	PV1 Current	Actual value	Value	1/0/5	4 bytes	C	R	-	T	-	electric cur...	Low
24	AC Power	Actual value	Value	1/0/6	4 bytes	C	R	-	T	-	power (W)	Low
25	DC Power	Actual value	Value	1/0/7	4 bytes	C	R	-	T	-	power (W)	Low
26	AC Frequency	Actual value	Value	1/0/8	4 bytes	C	R	-	T	-	frequency...	Low
27	AC Apparent power	Actual value	Value	1/0/9	4 bytes	C	R	-	T	-	power (W)	Low
28	AC Reactive power	Actual value	Value	1/0/10	4 bytes	C	R	-	T	-	power (W)	Low
29	AC power factor	Actual value	Value	1/0/11	4 bytes	C	R	-	T	-	power fact...	Low
30	AC Energy	Actual value	Value	1/0/12	4 bytes	C	R	-	T	-	active ener...	Low
31	Inverter efficiency	Actual value	Value	1/0/13	2 bytes	C	R	-	T	-	percentag...	Low
32	Inverter resistance	Actual value	Value	1/0/14	4 bytes	C	R	-	T	-		Low
33	Cabinet Temperature	Actual value	Value	1/0/15	2 bytes	C	R	-	T	-	temperatu...	Low
34	Manufacturer specific status code	Status code	Value	1/0/16	2 bytes	C	R	-	T	-		Low
35	Manufacturer specific status code	Status code	Value	1/0/17	2 bytes	C	R	-	T	-		Low
36	Manufacturer specific status code	Status code	Value	1/0/18	2 bytes	C	R	-	T	-		Low
37	Manufacturer specific status code	Status code	Value	1/0/19	2 bytes	C	R	-	T	-		Low
38	Manufacturer specific status code	Status code	Value	1/0/20	2 bytes	C	R	-	T	-		Low
39	Manufacturer specific status code	Status code	Value	1/0/21	2 bytes	C	R	-	T	-		Low

When GO and parameters are all configured, download the KNX Interface application to the device. The first download requires pressing the programming button on the device to set the device in KNX programming mode then perform a full download.

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 17 of 18


6.5 INVERTER CONFIGURATION

Modbus TCP must be enabled on the inverter, refer to the inverter user manual.

	User Manual	Doc.Ref : INV-KNX-GO-UM
	KNX Gateway for GoodWe Inverters	Revision : 2.00
		Page : 18 of 18

7. FIRMWARE VERSION

This user manual and related ETS application is valid for firmware versions V3.0.0.0 and above. The firmware version can be read from the gateway webpage using a web browser. It is displayed on the top right of the page.



In case an updated firmware would be available, the device can be updated from the FW Update page, the binary file should be selected before pressing the Update button.

8. DATASHEET

TECHNICAL DATA	VALUE
Auxiliary power supply terminal	Screw terminal 12-30VDC / GND
Power consumption KNX bus typ.	< 16 mA @ 29VDC
Operating temperature	+5°C to + 45°C
Enclosure Dimensions (Space Units)	2 SU
Mounting	DIN RAIL
KNX terminal	Pluggable micro terminal, Red/Black, 4 pole PUSH WIRE for solid conductor wire 0.6-0.8 mm ²
KNX bus voltage	29 VDC